

Glossary



circuit breaker Switches off all electricity if the supply is overloaded.



ords Contain the electrical wires that carry the electricity from the switch to the appliance.



double adaptor Allows a single power point to supply electricity to two plugs.



electrical appliance Something that is used to cook, cool, heat, light or entertain and needs electricity to make it work.



electricity A form of energy needed to make some appliances work.



electrical wires Carry electricity around your house.



energy A force that can be used to make something work.



overhead powerlines Carry electricity from the power station to where it is needed.



plug Fits into the power point and receives electricity.



plug protector Fits into a power point to stop objects being poked into it.



power station The place where electrical energy is created.



safety switch Switches off all electricity if there is an electrical problem.



switches Stop and start the flow of electricity.



switchboard Contains the circuit breakers and safety switch for the house.